

Empowering your business, one transaction at a time.

Innovative payment solutions delivered with a personal touch.

Accept payment in-person or online with our innovative terminal solutions. Whether you need a stationary, wireless, mobile, or virtual terminal, a payment gateway, or software integration, ECS is the right choice for you.



Diverse solutions for every scenario.



Credit & Debit

With a diverse range of credit and debit card processing solutions, we have what you need.



ACH

Completely electronic, ACH transactions are efficient and low-cost.



ATM

Connect to all major ATM networks.



Banking

With a merchant bank account, you'll have access to our affordable rates and award-winning merchant services team.



High-Risk

We're built to handle complex merchants, regardless of your industry.



Lending

Lending your way to provide you with the instant capital you need.



Merchant Cash Advance

Access the assets your business deserves.



Remote Deposit Capture

With ECS, there's no need to go to the bank to cash payment checks.

To find out more [click here](#)



USA

Z1 Restaurant Quick Reference Guide



CREDIT SALE

1. From the **CREDIT SALE ENTER AMOUNT** enter credit sale amount and press **OK**
2. **Insert, Tap, Swipe OR Manually Enter Card #**
 - If AVS prompts, input AVS information
 - If Prompted for TIP input TIP Amount
3. Terminal communicates with the Host
4. Response Displays 

DEBIT SALE

1. From the **CREDIT SALE ENTER AMOUNT** Press the **F3** Key
3. Press the **F3** Key to **highlight DEBIT** and press **OK**
4. Input the Debit Sale **Amount** and press **OK**
 - If Prompted for TIP input TIP Amount
5. **Insert, Tap or Swipe Card #**
6. **Input PIN #** on PIN Pad and press **OK**
7. Response Displays 

TICKET ONLY SALE

1. From the **CREDIT SALE ENTER AMOUNT**
 2. Press the  yellow arrow key
 3. Scroll using the **F3** Key to highlight **TICKET** and press **OK**
 4. Input the ticket **Amount** and press **OK**
 5. Input previously obtained **AUTH CODE** and press **OK**
 6. **Insert, Tap, Swipe OR Manually Enter Card #**
 7. Response Displays 
- ** If/when prompted for Password, default is 1234

VOID TRANSACTION

1. From the **CREDIT SALE ENTER AMOUNT**
2. Press the  yellow arrow key
3. Scroll using the **F3** Key to highlight **VOID** and press **OK**
4. Input the **Amount to be Voided** and press **OK**
5. Press **F1** to confirm Void Amount
6. **Insert, Tap, Swipe OR Manually Enter Card #**
7. Response Displays 

** If/when prompted for Password, default is 1234

RETURN TRANSACTION

1. From the **CREDIT SALE ENTER AMOUNT**
2. Press the  yellow arrow key
3. Scroll using the **F3** Key to highlight **RETURN** and press **OK**
4. Input the **Amount to be RETURNED** and press **OK**
5. Press **F1** to confirm Void Amount
6. **Insert, Tap, Swipe OR Manually Enter Card #**
7. Response Displays 

** If/when prompted for Password, default is 1234

SETTLE THE OPEN BATCH

1. From the **CREDIT SALE ENTER AMOUNT** press the **OK** button three (3) times.
3. **Input Password** (1234 Default) and press **OK**
4. Terminal communicates with the Host
5. Response Displays 

